


FITTING INSTRUCTION

Clamp mark in acc. with		Cables joining
ISO	PN	
1	L	Left directional lights
2	+	Rear fog lights
3	31	Ground
4	R	Right directional lights
5	58R	Right side parking lights
6	54	Stoplights
7	58L	Left side parking lights



This towing hitch is designed to assembly in following cars: **MITSUBISHI PAJERO, V20, (V2/V4), 3/5 doors**, produced since 1991 till 2000, catalogue no. **Z02** and is prepared to tow trailers max total weight **3300 kg** and max vertical mass **135 kg**.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be install in points described by a car producer.

INSTRUCTIUNI MONTAJ

1. Aplică bara principală a cârlig de remorcare (poz. 1) de la partea de jos a masinii la cadrul masinii. Apoi fixati prin găurile laterale ale cârlig de remorcare existente gauri ale ramei auto cu ajutorul șuruburilor M12x1.25x55mm (poz. 7) și M12x120mm (poz. 4) de la cârlig de remorcare accesorii - vezi desenul.
2. Fix-remorcare mingii (poz. 2), folosind șurubul M12x75mm (poz. 5) și M12x70mm (poz. 6). Cu șurub M12x75mm fixa, de asemenea, o placă de soclu (poz. 3). A se vedea figura 1.
3. Strângeți toate șuruburile conform cu cuplul este prezentat în tabel.
4. Conectați cablurile electrice de priză cu 7 poli de conform formulei instruirea masinii. (Montaj in atelier auto autorizat).

Torque settings for nuts and bolts (8,8):	
M 8 - 25 Nm	M 10 - 55 Nm
M 12 - 85 Nm	M 14 - 135 Nm













NOTE

After install the towing hitch you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.

Towing hitch accessories:

Pos. 1	Main bar	Pos. 5	Bolt 8,8 B M12x75mm	Pos. 10	Washer ø37xø13x3mm
PCS.: 1		PCS.: 1		PCS.: 2	
		Pos. 6	Bolt 8,8 B M12x70mm	Pos. 11	Spring washer ø12mm
		PCS.: 1		PCS.: 10	
Pos. 2	Tow ball	Pos. 7	Bolt 8,8 B M12x1.25x55mm	Pos. 12	Ball cover
PCS.: 1		PCS.: 4		PCS.: 1	
Pos. 3	Socket plate	Pos. 8	Nut 8 B M12		
PCS.: 1		PCS.: 4			
Pos. 4	Bolt 8,8 B M12x120mm	Pos. 9	Plain washer ø12mm		
PCS.: 2		PCS.: 8			

S.C. AUTO GEDAL IMPEX S.R.L.

Tel: +40 745.805.990 / +40 737.122.471

Email: autogedal@gmail.com

office@auto-hak.ro

Web Page: www.auto-hak.ro

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **Z02**

Designed for:

Manufacturer: **MITSUBISHI**

Model: **PAJERO, V20, (V2/V4)**

Type: **3/5 doors**

produced since 1991 till 2000

Technical data:

D-value: 14,3 kN

maximum trailer weight: **3300 kg**

maximum vertical cup mass: **135 kg**

Approval number acc. to regulations EKG/ONZ 55.01: E20-55R-01 0864

Foreword

This towing hitch is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer mass and max. vertical cup mass are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$