


FITTING INSTRUCTION

Clamp mark in acc. with		Cables joining
ISO	PN	
1	L	Left directional lights
2	+	Rear fog lights
3	31	Ground
4	R	Right directional lights
5	58R	Right side parking lights
6	54	Stoplights
7	58L	Left side parking lights



This towing hitch is designed to assembly in following cars: **SUZUKI VITARA, 5 doors**, produced since 1995, catalogue no. **W05** and is prepared to tow trailers max total weight **1875 kg** and max vertical load **75 kg**.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be install in points described by a car producer.

INSTRUCTIUNI MONTAJ

1. Demontați ochi originale de remorcare (nu va mai fi folosit).
2. Puneți bara principală a cârlig de remorcare (poz. 1) dedesubt la masina la șasiu cadru și prin găurile A și original găuri filetate în rama fixa cu șuruburi M12x1.25x35mm (poz. 5) de la tractarea accesorii de remorcare.
3. Pentru a bara de instalat cârligului de tractare fixa bara de remorcare (poz. 2) cu ajutorul șuruburilor M16x50mm (poz. 4), de la accesorii.
4. Se fixează placa soclu (poz. 3), folosind șurubul M10x30mm (poz. 6).
5. Strângeți toate șuruburile conform cu cuplul este prezentat în masa.
6. Conectați cablurile electrice de priză cu 7 poli de conform formulei instruirea masinii. (Recomandat montajul la atelier auto).

Torque settings for nuts and bolts (8,8):

M6 - 11 Nm
M12 - 87 Nm

M8 - 25 Nm
M14 - 138 Nm

M10 - 50 Nm
M16 - 210 Nm
















NOTE

After install the towing hitch you should get adequate note in registration book (at authorised service station).The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km check all bolts. The ball of towing hitch must be always kept clear and conserve with a grease.

Towing hitch accessories:

Pos. 1	Main bar 	Pos. 5	Bolt 8,8 B M12x1.25x35mm 	Pos. 10	Plain washer ø13mm 
PCS.: 1		PCS.: 4		PCS.: 4	
Pos. 2	Tow ball 	Pos. 6	Bolt 8,8 B M10x30mm 	Pos. 11	Plain washer ø10.5mm 
PCS.: 1		PCS.: 1		PCS.: 1	
Pos. 3	Socket plate 	Pos. 7	Nut 8 B M16 	Pos. 12	Spring washer ø16.3mm 
PCS.: 1		PCS.: 2		PCS.: 2	
Pos. 4	Bolt 8,8 B M16x50mm 	Pos. 8	Nut 8 B M10 	Pos. 13	Spring washer ø12.2mm 
PCS.: 2		PCS.: 1		PCS.: 4	
		Pos. 9	Plain washer ø17mm 	Pos. 14	Spring washer ø10.2mm 
		PCS.: 2		PCS.: 1	
			Pos. 15	Ball cover 	
			PCS.: 1		

S.C. AUTO GEDAL IMPEX S.R.L.
 Tel: +40 745.805.990 / +40 737.122.471
 Email: autogedal@gmail.com
 office@auto-hak.ro
 Web Page: www.auto-hak.ro

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **W05**

Designed for:

Manufacturer: **SUZUKI**

Model: **VITARA**

Type: **5 doors**
 produced since 1995

Technical data:

D-value: 9,2 kN

maximum trailer weight: **1875 kg**

maximum vertical cup load: **75 kg**

Approval number according to Directive 94/20/EC: e20*94/20*0478*00

Foreword

This towing hitch is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$